


The right way:



The wrong way:



Also important:




Before you start, make shure the yellow gaz tap of the burner is open.

The next step:




Step 4. Slowly turn the bolt in the direction of the arrow until you hear the gas coming out of the burner. You can now light the burner with a lighter.

Light the burner in the following way:



Correct position of the burner:



After the burner is lit, you can place the burner on the rim of the burner hole of the Raku kiln. (or just a little outside the burner hole)

Correct position of the burner part 2:



Wrong position of the burner:

